

# Introduction to LabVIEW

## TOPICS

- A. What Is LabVIEW?
- B. Background Information
- C. LabVIEW Example Demo
- D. Basic File Types
- E. Parts of a VI
- F. Front Panel Design
- G. Block Diagram and Searching
- H. Tool, Wiring and Debugging
- I. LabVIEW Data Types
- J. Program Flow Control

---


# A. What Is LabVIEW?

Lab Virtual Instrument Engineering Workbench

LabVIEW Language Feature

# What Is LabVIEW?

— A graphical programming environment used to develop sophisticated measurement, test, and control systems.



LabVIEW:

- Interfaces with wide variety of hardware
- Scales across different targets and OSs
- Provides built-in analysis libraries

# LabVIEW Language Characteristics

## Basic

- Graphical
- Dataflow-oriented
- Multi-threaded
- Multi-platform
- Synchronous

## Advanced

- Event-driven
- Object-oriented
- Multi-language
- Multi-target
- Memory-Managed

---

# B. Background Information

Hardware Integration

LabVIEW Projects

# NI Hardware



**PXI**



**myRIO**



**cRIO**




**DAQ**

# SpaceX Control Center




# Wind Turbine Installation





# Wearable Robotics with cRIO



# MyRIO System Overview



## Features

- Portable
- Programmed with LabVIEW
- Powerful
- Multifunctional
- Expandable

## Resources

- Real Time System
- On board FPGA
- Wifi capability
- ADC/DAC
- UART/SPI/I2C

---

## C. LabVIEW Example Demo

3D Bouncing Ball

2D Robot Manipulator

Quadcopter Dynamics

---

## D. Basic File Types


Project Explorer Window

Virtual Instrument

Custom Controls

# Project Explorer

- Find, access, and organize project files
- Prevent, detect, and resolve incorrect links
- Deploy or download files to targets
- Manage code for build options
  - Executables, installers, and zip files
- Integrate with source code control providers




# LabVIEW Files

Common LabVIEW file extensions:

LabVIEW project — .lvproj

Virtual instrument (VI) — .vi

Custom control — .ctl



# Adding Folders to a Project




## Virtual folder

- Organizes project items and does not represent files on disk



## Auto-populating folder

- Adds a directory on disk to the project
- LabVIEW continuously monitors and updates the folder according to changes made in the project and on disk



---

## E. Parts of a VI

Front Panel

Block Diagram


Icon

Connector Pane



# Parts of a VI


VIs have 3 main components:



# Parts of a VI – Front Panel

## Front Panel – User interface for the VI


You build the front panel with controls (inputs) and indicators (outputs).



# Parts of a VI – Block Diagram

**Block Diagram** – Contains the graphical source code


Front panel objects appear as terminals on the block diagram.



# Parts of a VI – Icon/Connector Pane



**Icon** – Graphical representation of a VI



**Connector Pane** – Map of the inputs and outputs of a VI

Icons and connector panes are necessary to use a VI as a subVI.

- A subVI is a VI that appears on the block diagram of another VI.
- A subVI is similar to a subroutine or function in a text-based programming language.

---

# F. Front Panel Design

Controls and Indicators

Object Styles



Object Types

- Boolean

- Numeric

- String

# Front Panel




# Controls and Indicators

## Controls


- Input devices
- Knobs, buttons, slides
- Supply data to the block diagram

## Indicators

- Output devices
- Graphs, LEDs
- Display data the block diagram acquires or generates




# Front Panel Object Styles






# Numeric Controls and Indicators

The numeric data in a control or indicator can represent numbers of various types, such as integer or floating-point.




# Boolean Controls and Indicators

- The Boolean data type represents data that has only two options, such as True/False or On/Off.
- Use Boolean controls and indicators to enter and display Boolean (TRUE/FALSE) values.
- Boolean objects simulate switches, push buttons, and LEDs.



# Strings

- The string data type is a sequence of ASCII characters .
- Use string controls to receive text from the user, such as a password or user name.
- Use string indicators to display text to the user.



---



# G. Block Diagram and Searching

Terminals, Nodes, SubVIs, Wires

Context Help, LabVIEW Help, Example

Searching on Palettes, Quick Drop


# Block Diagram




# Block Diagram

Block diagram items:


- Terminals
- Constants
- Nodes
  - Functions
  - SubVIs
  - Structures
- Wires
- Free labels



# Terminals




Same label name



# Terminals for Front Panel Objects






- Terminals are:
  - Entry and exit ports that exchange information between the front panel and block diagram.
  - Analogous to parameters in text-based programming languages.
- Double-click a terminal to locate the corresponding front panel object.






# View Terminals as Icons

- By default, **View as Icon** option enabled.
- Deselect **View as Icon** for a more compact view.




# Nodes

Nodes are objects on the block diagram that have inputs and/or outputs and perform operations when a VI runs.




# Function Nodes



- Functions are:
  - Fundamental operating elements of LabVIEW.
  - Do not have front panels or block diagrams, but do have connector panes.
  - Has a pale yellow background on its icon.
- Double-clicking a function only selects the function.
- Functions do not open like VIs and subVIs.

# SubVI Nodes


Write To Spreadsheet File.vi



- SubVIs :
  - Are VIs that you use on the block diagram of another VI.
  - Have front panels and block diagrams.
  - Use the icon from the upper-right corner of the front panel as the icon that appears when you place the subVI on a block diagram.
- When you double-click a subVI, the front panel and block diagram open.
- Any VI has the potential to be used as a subVI.

# Express VIs













- Express VIs:
  - Are a special type of subVI.
  - Require minimal wiring because you configure them with dialog boxes.
  - Save each configuration as a subVI.
- Icons for Express VIs appear on the block diagram as icons surrounded by a blue field.




# Wires



- Wires transfer data between block diagram objects.
- Wires are different colors, styles, and thicknesses, depending on their data types.
- A broken wire appears as a dashed black line with a red X in the middle.



	Floating-point	Integer	String	Boolean
Scalar				
1-D Array				
2-D Array				


# Context Help

- Displays basic information about wires and nodes when you move the cursor over an object.
- Can be shown or hidden in the following ways.
  - Select **Help»Show Context Help** from the LabVIEW menu.
  - Press <Ctrl-H>.
  - Click the following button on the toolbar: 



# LabVIEW Help


- Contains detailed descriptions and instructions for most palettes, menus, tools, VIs, and functions.
- Can be accessed by:
  - Selecting **Help» LabVIEW Help** from the menu.
  - Clicking the **Detailed help** link in the **Context Help** window.
  - Right-clicking an object and selecting **Help** from the shortcut menu.





# Examples

- LabVIEW includes hundreds of example VIs.
- Use NI Example Finder to browse and search installed examples.
  - Select **Help»Find Examples** in the menu.
- Click the example buttons in *LabVIEW Help* topics.



Open example



Find related examples


# Searching for Controls, VIs, and Functions

Ways to find controls, VIs, and functions:

- Search or navigate the palettes.
  - Controls palette
  - Functions palette
- Search by name of object.
  - Quick Drop dialog box
- Search palettes, *LabVIEW Help*, and `ni.com`.
  - Search text box in toolbar


# Controls Palette

- Contains the controls and indicators you use to create the front panel.
- Navigate the subpalettes or use the **Search** button to search the Controls palette.




# Functions Palette

- Contains the VIs, functions, and constants you use to create the block diagram.
- Navigate the subpalettes or use the **Search** button to search the Functions palette.




# Searching with Quick Drop

- Lets you quickly find controls, functions, VIs, and other items by name.
- Press the <Ctrl-Space> keys to display the Quick Drop dialog box.



# Global Search

Use the Search bar in the top right of the front panel and block diagram windows to search palettes, *LabVIEW Help*, and *ni.com*.



---

# H. Tool, Wiring and Debugging


Selecting a Tool

Wiring Clean-Up

Debugging

# Selecting a Tool


- A tool is a special operating mode of the mouse cursor.
- Create, modify, and debug VIs using the tools provided by LabVIEW.
- By default, LabVIEW automatically selects tools based on the context of the cursor.
- If you need more control, use the **Tools** palette to select a specific tool.
  - Select **View»Tools Palette** to open the **Tools** palette.





# Wiring Tips

- Press <Ctrl-B> to delete all broken wires.
- Right-click and select **Clean Up Wire** to reroute the wire.




# Debugging Techniques

What to look for if a VI produces unexpected data or behavior:

- Are there any unwired or hidden subVIs?
- Is the default data correct?
- Does the VI pass undefined data?
- Are numeric representations correct?
- Are node executed in the correct order?


# Execution Highlighting

- Use execution highlighting to watch the data flow through the block diagram.
- If the VI runs more slowly than expected, confirm that you turned off execution highlighting in subVIs.





# Single-Stepping

- Single-step through the VI to view each action of the VI on the block diagram.
- Suspend the execution of a subVI to edit values of controls and indicators, to control the number of times it runs, or to go back to the beginning of the execution of the subVI.
  - Open subVI and select **Operate»Suspend When Called** from the shortcut menu.




# Probes

- Use the Probe tool to observe intermediate data values and check the error output of VIs and functions, especially those performing I/O.
- Specify to retain the values in the wires so that you can probe wires for data after execution.



# Breakpoints

- When you reach a breakpoint during execution, the VI pauses and the **Pause** button appears red. 
- You can take the following actions at a breakpoint:
  - Single-step through execution using the single-stepping buttons.
  - Probe wires to check intermediate values.
  - Change values of front panel controls.
  - Click the **Pause** button to continue running to the next breakpoint or until the VI finishes running.

---

# I. LabVIEW Data Types

Shortcut Menu and Properties Dialog Box

Numeric Types


Boolean Types

String Types

Enums and Other Types

# LabVIEW Data Types


Terminals visually communicate information about the data type represented






# Shortcut Menu

- All LabVIEW objects have associated shortcut menus.
- Use shortcut menu items to change the look or behavior of objects.
- To access the shortcut menu, right-click the object.



# Properties Dialog Box

- All LabVIEW objects have properties.
- To access properties, right-click the object and select **Properties**.
- Property options are similar to shortcut menu options.
- Select multiple objects to simultaneously configure shared properties.





# Numerics

Various data type representations:


- Floating-point
- Unsigned integers
- Signed integers


DBL  



I32  


U32  


SGL  




I8  


U8  





# Numeric Conversion

- Coercion dots indicate that LabVIEW converted the value passed into a node to a different representation.
  - Occurs when a node expects an input with a different representation.
- LabVIEW chooses the representation that uses more bits.
- Avoid coercion by programmatically converting to a matching data type.



# Booleans

- Behavior of Boolean controls is specified by the mechanical action.
- Boolean have only TRUE/FALSE values.



Boolean - Switch




True Constant



Boolean - Latch




False Constant



# Strings

- A string is a sequence of ASCII characters.
- Strings have various display styles.
  - Backslash codes
  - Password
  - Hex



String Control



Empty String Constant



String Indicator




String Constant



Tab Constant





End of Line Constant






# Enums

- Enums give users a list of items from which to select.
- Each item represents a pair of values.
  - String
  - 16-bit Integer



# Other Data Types

Refer to *LabVIEW Help* for complete list of terminal symbols for different types of controls and indicators.

- Dynamic 
  - Stores the information generated or acquired by an Express VI.
- Path 
  - Stores the location of a file or directory using the standard syntax for the platform you are using.
- Waveform 
  - Carries the data, start time, and dt of a waveform.



---

# J. Program Flow

Data Flow

Case Structure


Loops

Timing

# Dataflow

LabVIEW follows a dataflow model for running VIs.


- A node executes only when data are available at all of its required input terminals.
- A node supplies data to the output terminals only when the node finishes execution.



# Dataflow – Quiz

Which node executes first?

- a) Add
- b) Subtract
- c) Random Number
- d) Divide
- e) Sine




# Dataflow – Quiz Answers

No single correct answer.


Which node executes first?

- a) Add – **Possibly**
- b) Subtract – **Definitely not**
- c) Random Number – **Possibly**
- d) Divide – **Possibly**
- e) Sine – **Definitely not**




# Case Structures

- Have two or more subdiagrams or cases.
- Use an input value to determine which case to execute.
- Execute and display only one case at a time.
- Are similar to **case** statements or **if...then...else** statements in text-based programming languages.



# Case Structures


- Case Selector Label
  - Contains the name of the current case.
  - Has decrement and increment arrows.
- Selector Terminal
  - Lets you wire an input value, or selector, to determine which case executes.




# Input and Output Tunnels

You can create multiple input and output tunnels.


- Inputs tunnels are available to all cases if needed.
- You must define each output tunnel for each case.



# While Loops



LabVIEW While Loop



Flowchart

Repeat (code);  
Until Condition met;  
End;


Pseudo Code



# While Loops


## Iteration terminal

- Returns number of times loop has executed.
- Is zero-indexed.




## Conditional terminal

- Defines when the loop stops.
- Has two options.
  - Stop if True
  - Continue if True




# While Loops – Tunnels


- Tunnels transfer data into and out of structures.
- Data pass out of a loop after the loop terminates.
- When a tunnel passes data into a loop, the loop executes only after data arrive at the tunnel.



# For Loops



LabVIEW For Loop




Flowchart

```
N=100;  
i=0;  
Until i=N:  
    Repeat (code;i=i+1);  
End;
```

Pseudo Code

# For Loops – Conditional Terminal


You can add a conditional terminal to configure a For Loop to stop when a Boolean condition is true or an error occurs.



# For Loops – Conditional Terminal

For Loops configured with a conditional terminal have:


- A red glyph next to the count terminal.
- A conditional terminal in the lower right corner



# For Loop/While Loop Comparison



## For Loop

- Executes a set number of times unless a conditional terminal is added.
- Can execute zero times.
- Tunnels automatically output an array of data.




## While Loop

- Stops executing only if the value at the conditional terminal meets the condition.
- Must execute at least once.
- Tunnels automatically output the last value.




# Data Feedback in Loops

- When programming with loops, you often need to know the values of data from previous iterations of the loop.
- Shift registers transfer values from one loop iteration to the next.



# Shift Registers

- Right-click the border and select **Add Shift Register** from the shortcut menu.
- Right shift register stores data on completion of an iteration.
- Left shift register provides stored data at beginning of the next iteration.







# Initializing Shift Registers

Run once


VI finishes

Run again

Block Diagram	1st run	2nd run
<p>Initialized Shift Register</p> 	<p>Output = 5</p>	<p>Output = 5</p>
<p>Not Initialized Shift Register</p> 	<p>Output = 4</p>	<p>Output = 8</p>

# Multiple Previous Iterations


- Stacked shift registers remember values from multiple previous iterations and carry those values to the next iterations.
- Right-click the left shift register and select **Add Element** from the shortcut menu to stack a shift register.



# Timing a VI

Why do you need timing in a VI?

- To control the frequency at which a loop executes.
- To provide the processor with time to complete other tasks, such as processing the user interface.




# Wait Functions



A wait function inside a loop:

- Allows the VI to sleep for a set amount of time.
- Allows the processor to address other tasks during the wait time.
- Uses the operating system millisecond clock.

Wait (ms)



Wait Until  
Next ms Multiple



# Elapsed Time Express VI

- Determines how much time elapses after some point in your VI.
- Keeps track of time while the VI continues to execute.
- Does not provide the processor with time to complete other tasks.



# Homework

- Complete the LabVIEW Beginner Homework
- Open-ended Problem:
  - Install the Arduino Package for LabVIEW
  - Establish communication between Arduino and LabVIEW
  - Use any sensor that you learned earlier and plot the measurement on the screen in real time with LabVIEW

# Questions?

- Online Resources:
  - [Self-Paced Online Training](#)
  - <http://www.learnni.com/>
  - [LabVIEW 101 Slides](#)